

AJP 8




Main Assembly

Clean the crank nose pinion.




Main Assembly

Insert the drive key, and celoc pins.



Main Assembly

Next clean and degrease the nose pinion bolt and dry...



Main Assembly

...then apply loctite studlock.