




Main Assembly

... fit spacer key and polyvee pulley.




Main Assembly

Push the jackshaft in as far as it will go to seat the lip seal.



Main Assembly

Loosely fit the pulley, washer, and nut.



Main Assembly

Wash the jackshaft key and caphead, dry and apply loctite...