

Main Assembly continued...




Main Assembly

Fit the alternator bracket, wash the mounting capheads and loctite...




Main Assembly

...torqueing to 20 ft lbs.



Main Assembly

Fit the alternator pivot bolt.



Main Assembly

...and nyloc nut.