

AJP 8




Main Assembly

Clean the oil transfer pipe thoroughly.




Main Assembly

Fit the O-rings...



Main Assembly

...and apply rubber grease.



Main Assembly

Fit using capheads, remembering to clean and loctite them.